



LEDVANCE PV MODULES INSTALLATION MANUAL



CONTENTS

LEDVANCE PV MODULES INSTALLATION MANUAL

INTRODUCTION FOR USER MANUAL	3
Disclaimer	3
Limitation of liability	3
SAFETY PRECAUTIONS	4
Warning	4
General safety	4
Handling safety	5
UNLOAD/TRANSPORTATION/STORAGE	6
Markers on outer packaging	7
Unloading warning	8
Secondary transport and warning	9
Storage	10
UNPACKING SAFETY	11
INSTALLATION	12
Installation safety	12
Environment conditions and site selection	13
Tilt angle of modules	14
Installation method – mechanical installation and warning	16
Installation method – electrical installation	21
MODULE MAINTENANCE	27
Panel visual inspection and replacement	27
Connector and cable inspection	28
Cleaning	28
Module inspection after cleaning	29
Troubleshooting	30

INTRODUCTION FOR USER MANUAL

This general manual applies to the installation, maintenance and use of the solar modules manufactured by LEDVANCE GmbH (hereinafter referred to as „LEDVANCE”). Failure to follow these instructions could result in personal injury or property damage.

LEDVANCE GmbH

Installation and operation of PV modules requires professional skills and should only be performed by qualified professionals. Read the „Safety and Installation Instructions” carefully before using and operating the modules.

The word „module” or “PV module” used in this manual refers to one or more solar modules. Keep this manual for future reference.

DISCLAIMER

- LEDVANCE reserves the rights to change this User Manual without prior notice. Refer to our product lists and documents published on our website at: www.ledvance.com as these lists are updated on a regular basis.
- Failure of the customer to follow the requirements outlined in this Manual during the installation of the module will result in the invalidity of product’s limited warranty.
- LEDVANCE is not responsible for any infringement of third party patents or any other rights arising from the use of solar PV modules.
- The information in this manual is based on LEDVANCE’s knowledge and experience and is believed to be reliable, but such information including product specification (without limitations) and suggestions do not constitute a warranty, expresses or implied.

LIMITATION OF LIABILITY

LEDVANCE is not responsible for any form of damage, including but not limited to module operation and system installation error, and personnel injury, hurt, and property loss resulting from failure to follow the instructions in this Manual.

SAFETY PRECAUTIONS

WARNING

Before attempting to install, wire, operate and/or service the module and other electrical equipment, all instructions should be read and understood. Direct current (DC) is generated when the battery surface of the module is exposed to direct sunlight or other light sources, and direct contact with the live parts of the module, such as terminals, may result in death of personnel whether connected to the module or not.

GENERAL SAFETY


LEDVANCE modules are designed to meet the requirements of IEC 61215 and IEC 61730, application class A. Modules rated for use in this application class may be used in system operating at greater than 50V DC or 240W, where general contact access is anticipated. Modules qualified for safety through IEC 61730-1 and IEC 61730-2 and within this application class are considered to meet the requirements for safety class II equipment.

- All installation work must comply with the local codes and the relevant international electrical standards.
- Only authorized and trained personnel should have access or perform work on the modules or solar system, always wearing rubber gloves and boots with maximum working voltage not lower than 1500V DC.
- Do not allow unauthorized persons to access the installation area or module storage area.
- Protective clothing (non-slip gloves, clothes, etc.) must be worn during installation to prevent direct contact with 30V DC or greater, and to protect hands from sharp edges.
- Prior to installation, remove all metallic jewelry to prevent accidental exposure to live circuits.
- Use electrically insulated tools to reduce the risk of electric shock.
- Do not use or install broken modules.
- External or artificially concentrated sunlight shall not be directed onto the front or back face of the PV module.
- Do not touch module surface if the front/rear glass or backsheet is broken/damaged. This may cause electric shock.
- Do not attempt to repair, disassemble, move any part of the PV module. The module does not contain any reusable parts.
- Do not connect or disconnect the module when it is energized.

SAFETY PRECAUTIONS

HANDLING SAFETY

Do not stand, walk on or lean on the module directly.



- Do not damage or scratch the front or backside surfaces of the module.
- Do not pull, scratch, bend the output cable with force or with too tight connection. The insulation of output cable can break and may result in electricity leakage or shock.
- If there is an open fire, extinguish it with a dry powder extinguisher after disconnecting the power supply, don't use liquid such as water to extinguish the fire.
- Do not install or handle modules when they are wet or during periods of high wind.
- At the installation site, take care to keep modules and in particular their electrical contacts, clean and dry before installation. If connector cables are left in damp conditions then the contacts may corrode. Any module with corroded contacts should not be used.
- Do not loosen, unscrew or peel the PV module bolts and frame glue. This may lead to a reduction of the module's load rating and potential damage from a fall.
- Do not drop PV modules or allow objects to fall down on the PV modules.
- Do not touch the terminal box or the ends of the output cables (connectors) with bare hands under sunlight, regardless of whether the PV module is connected to or disconnected from the system.
- Do not dispose the modules at random locations; special recycling is required.

UNLOAD/TRANSPORTATION/STORAGE

Precautions and general safety rules:


- Modules should be stored in a dry and ventilated environment to avoid direct sunlight and moisture and extra precautions should be taken to prevent connectors from being exposed to moisture or sunlight, like using connector endcaps.
- The modules should be stored in the original LEDVANCE package before installation. Protect the package from damage. The whole process of transport, storage and unpacking should be handled with care.
- Before installation, ensure that all modules and electrical contacts are clean and dry.
- Unpacking must be carried out by two or more persons at the same time.
- Handling the modules requires two or more people with nonslip gloves and both hands.
- Do not lift modules by their wires or junction box.
- Do not handle the modules over-head.
- Do not place excessive loads on the module or twist the module.
- Do not drop or place objects (such as tools) on the modules.
- Do not put the modules in a place that is not supported or stable.
- Do not allow the modules to come in contact with sharp-pointed objects to prevent them from scratches, avoiding a direct impact on the safety of modules.
- Do not expose the modules and its connectors to any chemical substance (e.g. oil, lubricant, pesticide, etc.).
- Modules should be fastened with net ropes for transportation with secondary vehicle.
- In any circumstances, for vertical landscape packages, it shall not be stacked more than two layers; for vertical portrait packages, stacking is not allowed. Example for vertical landscape package and vertical portrait package is shown as follows:



Vertical landscape package
(short-side vertically placed)



Vertical portrait package
(long-side vertically placed)



Right
Examples

UNLOAD/TRANSPORTATION/STORAGE

MARKS ON OUTER PACKAGING




Need both hands to handle it carefully.



Uninstalled modules must be kept dry, not exposed to rain or moisture.



Modules in carton are fragile, which must be handled with care.



The packaging must be transported upright.



Do not step on the package and module.



Modules should be stacked as required, not exceeding the maximum number of layers printed on the outer packaging. (no more than two layers).




One module must be carried out by at least two persons together. Modules are placed vertically.

UNLOAD/TRANSPORTATION/STORAGE

UNLOADING WARNING







1. When crane is used to unload the modules, choose and use specialized tooling according to the weight and size of the module. Before lifting, check whether the tray and the carton are damaged and whether the hoisting ropes are strong and firm. Adjust the position of the sling to keep the modules steady. To ensure the safety of the module, wooden sticks, boards or other fixtures of the same width as the outer packing cases should be used on the upper part of the box to prevent the sling from squeezing the pallet and damaging the modules. When placing the modules, do not lower the packing box too quickly. Two people shall support at the two sides of the righting carton gently to place it on a flat ground. For vertical landscape packages, do not lift up more than FOUR pallets of modules at once; for vertical portrait packages, do not lift up more than TWO pallet of modules at once. Do not unload modules under the weather conditions of wind more than class 6 (in Beaufort scale), heavy rain or heavy snow.
2. Use a forklift to remove the module pallets from the truck.
3. Put the modules on level ground.
4. Do not stack the modules at the project site.
5. Store the module in a dry and ventilated place.
6. Cover the module with waterproof material to prevent it from moisture.



UNLOAD/TRANSPORTATION/STORAGE

SECONDARY TRANSPORT AND WARNING

1. Do not remove the original packages if the modules require long-distance transport or long-term storage.
2. Packaged products can be transported by land, sea or air. During transportation, make sure that the package is fixed securely to the shipping platform without movement. Do not Stack more than two layers on truck.
3. Only one layer stacking is allowed for transport at the project site.
4. Do not transport the module with rope as shown below.
5. Do not carry the modules on the back of one person as shown below.
6. Do not allow pallets to exceed the loading area of the transport vehicle.



UNLOAD/TRANSPORTATION/STORAGE

STORAGE

- Do not remove the original packaging if the module requires long-distance transport or long-term storage.
- Do not expose the modules to rain or moisture. Store the finished product in a well ventilated, waterproof, dry and smooth surface.
- Do not stack modules more than 2 layers for vertical landscape packages. Do not stack modules more than 1 layer for vertical portrait packages.
- The module must be installed as soon as possible in the project site and must not be exposed to rain or damp. LEDVANCE will not be responsible for any damage or collapse of the modules caused by moisture in the packaging. Moisture<85%RH, temperature range from -40°C to + 50 °C.
- For long-term storage, it is recommended to store the modules in a standard warehouse with regular inspection, and under confirming of your personal safety, reinforce the package in a timely manner if any anomalies are found.
- If you need to store the modules in the project site, choose a hard ground or a higher ground with flat surface to ensure the module packages not collapsing and tilting for long-term storage.
- Do not allow unauthorized persons to access the module storage area.
- Do not leave modules unsupported or unsecured.
- The modules should be centrally stored with pallet spacing within 10cm.

UNPACKING SAFETY

Unpacking modules outdoors under rainy conditions is prohibited. Because the carton will become soft and damaged after it gets wet in the rain. The stacked PV modules (hereinafter referred to as "modules") may tip over, which may cause damage or injury to personnel.


- For a windy site, it is necessary to pay special attention to safety. Especially, it is not recommended to transport or unpacking the modules in high wind conditions. The unpacked modules must be tied down to avoid any unwanted movement.
- The work surface is required to be level to ensure that the package can be placed stably, avoiding sliding.
- Wear protective gloves during unpacking to avoid hand injury and fingerprints on the glass surface.
- Each module shall be handled by two persons. It is forbidden to pull the wires or junction boxes and frame of the modules to carry the module.
- If all the modules are not taken out after unpacking, the remaining modules shall be placed horizontally and repackaged to prevent them from tipping. When packaging, note that the glass side of the bottom module should face up, the glass side of the middle modules should face down, and the glass side of the top module should face up. Stacks of modules should contain no more than 16 modules, and the frames should be aligned.

INSTALLATION

INSTALLATION SAFETY

– LEDVANCE modules can be mounted in landscape or portrait orientation. For all PV modules, LEDVANCE does not recommend short side installation.

Installation mode in the long side



- Always wear dry insulation protection equipment: insulated tools, head gear, insulated gloves, safety belt and safety shoes (with rubber soles and safety cups).
- Make sure flammable gasses are not generated or present near the installation site.
- Do not install modules under rain, snow or windy conditions. Place disassembled PV modules correctly.
- Keep the PV module packed in the carton until installation. Install immediately after unpacking, keep the connector dry and clean during installation to avoid the risk of electric shock. Do not perform any work if the terminals of PV module are wet, until they are dry.
- Do not touch the junction box and the end of the interconnect cables (connectors) with bare hands during installation or under sunlight, regardless of the PV module is connected to or disconnected from the system.
- During installation, if PV modules are touched by bare hands, there is a risk of scalding or electric shock.
- Do not hit or put excessive load on the front or back of PV modules, this may break the cells or cause microcracks.
- Do not unplug the connector under load.
- Do not stand on the module glass. There is a risk of injury or electric shock if glass is broken.
- Do not work alone (always work as a team of 2 or more people).

INSTALLATION

- Do not damage the back sheet of PV modules when fastening the PV modules to a support with bolts.
- Do not drill holes in the frame. It may cause corrosion of the frame or PV modules burst.
- Do not damage the surrounding PV modules or mounting structure when replacing a PV module.
- Cables must be fixed in the area not exposed to direct sunlight to prevent cables aging.
- Protective measures must be taken in the process of installation to avoid force extrusion or impact on the modules.
- When installing modules on roof mounted structures, try to follow the “from top to bottom” and/or “from left to right” principle, and don’t step on the module. Step on modules will damage the module and would be dangerous for personal safety.
- The design loading of modules have been evaluated by TÜV according to IEC61215 with 1.5 times safety factor; The mechanical load bearing is dependent upon the mounting methods used and failure to follow the instructions of this manual may result in different capabilities to withstand snow and wind loads. The system installer must ensure that the installation methods used meet these requirements and any local codes and regulations.
- We recommend that you insure your solar system against natural hazards (e.g. against lightning strikes).

ENVIRONMENT CONDITIONS AND SITE SELECTION

LEDVANCE module should be installed in the following environmental conditions.

NO	Environmental conditions	Range
1	Ambient temperature	-5°C ~ +40°C
2	Operating temperature	-40°C ~ +85°C
3	Storage temperature	-40°C ~ +50°C
4	Humidity	<85RH%

Table: Operations conditions

Remarks: The working environment temperature is the monthly average maximum temperature and minimum temperature of the installation site. The mechanical load bearing capacity of the solar PV modules is determined based on the installation method. The professional solar PV system installer must be responsible for calculating the solar PV system mechanical load bearing capacity.

The modules are certified according to the norm IEC 61215 and others for safe operation in moderate climates. The operator needs to consider the effect of the high altitude on the operation of the module, when the modules are installed at high altitude. The maximum altitude allowed for PV Module installation is 2000m.

For most places, LEDVANCE PV modules should be installed where the sunlight can be maximally acquired throughout the year. In the Northern Hemisphere, the PV modules should typically face south, and in the Southern Hemisphere, the PV modules should typically face north.

When selecting the installation location, avoid areas with trees, buildings, or obstacles because these objects will form shadows on solar PV modules, especially when the sun is at the lowest position on the horizon in winter. The shadow will cause the loss of the output power of the solar photovoltaic system. Although the bypass diode installed in the PV module can reduce this loss to some extent, do not ignore the shadow factor.

INSTALLATION

Do not install solar PV modules near fire or flammable materials. Do not install solar PV modules where there is water soaking, sprinkler or water spray.

Position the modules to minimize the chances of shading at all times of the day. Try to install modules in a location where there is rare shading throughout the year.

According to IEC 61701, salt mist corrosion testing of photovoltaic (PV), LEDVANCE PV modules can be installed in corrosive salt areas within proximity of the ocean or sulfurous areas. The module must not be soaked in the water or in the environment (i.e., fountain, spindrift, etc.) where the module would touch water (pure water or brine) for a long term. If the modules are placed in an environment of salt fog (i.e., marine environment) or sulfur (i.e., sulfur sources, volcanoes, etc.), there is a risk of corrosion. It's not recommended to install the modules, when the distance is less than 100m ; and it's recommended to install the modules with the anti-salt function, when the distance is between 100m and 1km. So stainless steel or aluminum materials must be used to contact the PV modules, and the installation position must be processed with anti-corrosion treatment. When modules are installed on land less than 1km away from the sea or in an area where the annual rainfall hours / total annual hours exceed 25%, the connectors are recommended to install waterproof cold shrinkable tubes to prevent the connector from water inlet and corrosion; Silicone rubber is recommended for the material of cold shrinkable tube.

According to IEC62716 "Ammonia corrosion testing of photovoltaic (PV) modules", LEDVANCE modules can be safely installed in ammonia-heavy environments, such as farm, meadow and so on.

Depending on the surrounding environment of the project, use the appropriate protective measures to ensure the safety of the module installation and reliable. For example, it needs to have windproof measures like windbreaks in strong wind area.

The system design needs to have the lightning protection function and the implementation of the grounding system for the installation location.

When installing PV modules on a roof, the roof must be covered with a layer of fireproof material applicable to it's class, and adequate ventilation must be ensured between the back of the module and the installation surface. A safe working area also must be left between the edge of the roof and the external edge of the solar array.

In the case of residential installations on the ground, modules must be installed following local regulations, e.g. using fence.

TILT ANGLE OF MODULES


The installation of PV module string should be in the same orientation and the same tilt angle. Different orientations and tilt angles will lead to the mismatches in current and voltage which is caused by different light absorption of different PV modules, causing loss of power of the PV system.

INSTALLATION

The largest power will be generated when direct sunlight on solar PV module. Solar modules are recommended to be installed at an optimized tilt angle to maximize the energy output.

For detailed information on the best installation angle at your location, refer to standard solar photovoltaic installation guides or consult a reputable solar installer or systems integrator. Dust building up on the surface of the modules can impair module performance. LEDVANCE recommends installing the modules with a tilt angle of at least 10° , making it easier for dust to be washed off by rain. Any faults caused by and/or attributable to tilt angle less than 10 degrees are not covered by manufacturer's warranty. It is roughly equal to the latitude of the project site as a rule of thumb, facing toward the equator. Optimized system designs must incorporate other local requirements.

Installation inclination refers to the angle between the module and the ground plane, as shown in figure below.



INSTALLATION

INSTALLATION METHOD – MECHANICAL INSTALLATION AND WARNING

PV modules can be installed through clamp method. The modules must be installed according to the following examples and recommendations. If a different installation method is desired, please contact LEDVANCE customer service or technical support team for consultation. Improperly mounted modules maybe damaged. If alternative mounting method is used that has not been approved by LEDVANCE, the modules will not continue to carry a valid warranty.

Modules shall not be subjected to wind or snow loads which is exceeding the maximum permissible designed loads, and shall not be subjected to excessive forces due to the thermal expansion of the support structures. The selection and design of mounting bracket shall be carried out by professional system engineers after the load calculation according to the climatic conditions of the installation site. Ensure the installation method and supporting system of modules is strong enough to withstand all the load conditions. The Installer must provide this guarantee. The installation supporting system must be tested by the third-party organization with the analysis ability of Static Mechanical, according to the local national or international standards.

The modules shall be mounted on continuous rails that extend beneath the modules. If modules are mounted without continuous rails, the maximum allowable load will be reduced.

Ensure that the modules with the same color cells to be installed together.

A clearance of at least 115mm (recommended) is provided between modules and the surface of the wall or roof.

The minimum clearance between two adjacent modules must not be less than 10mm.

The module frame drain holes cannot be blocked in any situation during installation or use.

Always keep the back of the PV module from coming into contact with foreign bodies or support components, which may damage the module when it is subjected to mechanical load.

The module frames will warp at low temperature. Avoid the frame receiving the lateral tension and pressure, causing the frame off or crushing the glass.

The installation methods listed below are for your reference only. The PV system installer or the trained professionals should take the responsibility of the PV system design, mechanical load calculation, installation, maintenance and safety. LEDVANCE will not supply the related material for system installation.

INSTALLATION

The mounting method must not result in the direct contact of dissimilar metals with the aluminum frame of the Module as it will result in galvanic corrosion. IEC 60950-1 standard recommends metal combinations not exceed an electrochemical potential difference of 0.6V.

To maximize mounting longevity, LEDVANCE strongly recommends the use of corrosion proof (stainless steel) attachment accessories.

Secure the module in each mounting location with an M8 bolt and a flat washer, spring washer and nut and tighten to a torque of 16~20 Nm. The yield strength of bolt and nut should not be less than 450 MPa.

All parts in contact with the modules should use flat stainless steel washers of minimum 1.8mm thickness with an outer diameter of 20-24mm. (Except for Single-axis tracking system).

Flat stainless steel gaskets with a minimum thickness of 1.5mm and an external diameter of 16-20mm shall be used in all parts of the components connected to the Single-axis tracking system.


Tools: screwdriver, wrench, stainless steel screw/bolt, clamp, nut and spring washer, plain washer.

Mounting with Bolts


Modules can be attached using the mounting holes on the back of the module frame, by fixing the module to the support rails with bolts. One module generally has 4 or 8 mounting holes and is installed with M8 bolts. The mounting details are shown in the following figures.

Two support rails are needed under the PV module to make sure the mechanical load. The solar module can accept up to 5400Pa downforce load and 2400Pa uplift load. This load is an empirical value of a solar module based on a standard installation mode, and the specific information shall be consulted by LEDVANCE.

Please check below figure the reference material for installation with bolts.




Installation with bolts into 4 outer holes
(Beam perpendicular to long sides)



Installation with bolts into 4 outer holes
(Beam Parallel to long sides)

INSTALLATION



Mounting with Clamps.

It is recommended to use fixing bolt of at least M8. The length of clamp $\geq 60\text{mm}$, thickness $\geq 3\text{mm}$. The clamp shall not be malfunctioned due to deformation or corrosion during the loading process.

The clamp must overlap the module frame by at least 7mm but no more than 10mm.

Use at least 4 clamps to attach modules to the mounting rails.

Modules clamps should not come into contact with the front glass and must not deform the frame.




Be sure to avoid shadowing effects on the solar cells from the module clamps.

The module frame is not to be modified under any circumstances.

When choosing this type of clamp-mounting method, use at least four clamps on each module, two clamps should be attached on each long sides of the module (for portrait orientation) Depending on local wind and snow loads, additional clamps may be required to ensure that modules can bear the load.

Applied torque should refer to mechanical design standard according to the bolt customer is using, ex: M8 16-20Nm.

INSTALLATION

End Clamp installation		Middle Clamp installation	
			
Module	Mechanical loading	Middle Clamp installation	
Length ≤ 2300mm	Front side ≤ 5400Pa Back side ≤ 2400Pa	 <p style="text-align: center;">$A = 1/4L \pm 50\text{mm}$; L=Module length</p> <p>NOTE:*</p> <ol style="list-style-type: none"> 1. The crossbeam is perpendicular to the long side frame. 2. The above described distance is from the module edge to the middle of the clamp. Clamps length ≥ 60mm. 3. Need two support rails below the PV module to make sure the Mechanical load. 	
2300 < Length ≤ 2500mm	Front side ≤ 3600Pa Back side ≤ 2400Pa		

***NOTES:** Other mounting configurations can be used. However, failure to comply with the above recommendations will result in a lowering of the load handling capabilities below the empirical value, and product failure as a result of an overload situation will not be covered by the LEDVANCE warranty.

Bifacial module can generate power after receiving reflected light on the back, which can bring additional power generation gain to the power station. Therefore, for bifacial module, it is recommended to install the beam parallel to long sides, so that there is no beam shielding directly below the module.

INSTALLATION

When the PV modules are installed with clamps on the corners as shown in below picture, the loading capacity will be reduced.



Please refer to below table for detail loading capacity.

Modules size (mm)	Test load (-) on rear side (in Pa)	Test load (+) on front side (in Pa)
1722 x 1134	1600	1600
1909 x 1134	1200	1200
2278 x 1134	800	800

***NOTES:** Other mounting configurations can be used. However, failure to comply with the above recommendations will result in a lowering of the load handling capabilities below the empirical value, and product failure as a result of an overload situation will not be covered by the LEDVANCE warranty.

Bifacial module can generate power after receiving reflected light on the back, which can bring additional power generation gain to the power station. Therefore, for bifacial module, it is recommended to install the beam parallel to long sides, so that there is no beam shielding directly below the module.

INSTALLATION

INSTALLATION METHOD – ELECTRICAL INSTALLATION

1. Electrical Connection

Precautions: To minimize risk in the event of an indirect lightning strike, avoid forming loops when designing the system. In order to avoid bad or damaged connection of the cable and connector, the cable and junction box caused by human factors, affecting the electrical safety or service life of the product, it is recommended that the force applied between the cable and connector, cable and junction box shall not be greater than 60N during the installation, dismantling, maintenance and any other related process of the Product.

Pay attention to the direction of the wire when installing the modules. It should be connected along the wire direction to avoid bending the wire.

The Direct Current (DC) generated by the PV system can be converted to Alternating Current (AC) and connected to the public power grid. Different regions may have different policies, laws and regulations to stipulate the installation and grid-connection requirements of PV systems. Therefore, during the design, installation and grid-connection of PV system, comply with the local policies, laws and regulations.

PV modules can obtain different current and voltage outputs through series and parallel connection. Read this installation manual carefully before starting electrical connection and installation.

Design and connect according to the current and voltage required by customers.

Before connection, ensure that the connection part is free from corrosion, and keep it clean and dry.

Different types of modules cannot be connected in series. Modules connected in series should ensure the consistency of their current (For the rest of modules with different current classes, the modules with adjacent current class can be installed in one given string.). The open circuit voltage of the module string should not exceed the allowable system voltage value, which can be found on the nameplate or datasheet of the module.

The standard copper cables applied in LEDVANCE modules are UV resistant and with a cross-sectional area of $\geq 4 \text{ mm}^2$ (12 AWG). All other cables used to connect the DC system should have a similar (or better) specification.

The maximum number of modules in series depends on the system design, the type of inverter used and the environmental conditions. In general, the maximum number (N) of PV modules in series can be calculated by dividing the maximum system voltage by the open circuit voltage of the relevant solar PV modules. When designing the solar PV system, it is necessary to take into account the characteristic that the voltage of the solar PV module changes with the temperature. Considering the voltage increase caused by temperature drop in extreme environment in winter, the maximum number of solar PV modules in series can be calculated by the following formula.

Maximum series connection number calculation

Formula	Maximum system voltage $V \geq N \cdot V_{oc} \cdot [1 + \beta \cdot (T_{min} - 25)]$
V	Maximum system voltage
N	The number of maximum solar PV modules in series
V_{oc}	The open circuit voltage of each module (see product label or datasheet) STC
β	Temperature coefficient of open circuit voltage of the module (refer to datasheet)
T_{min}	The lowest ambient temperature at installation site

INSTALLATION

The number of modules that can be connected shall be determined by a qualified institution or person in accordance with the design specifications of the photovoltaic system and the local electrical design specifications. The calculation formula recommended by LEDVANCE shall be for reference only.

If the modules are allowed to be installed in parallel electrically, each module (or series string of modules so connected) shall be provided with the maximum series fuse as specified. For applications requiring high currents, several photovoltaic modules or strings can be connected in parallel; the total current is equal to the sum of individual currents, each module (or series string of modules so connected) shall be provided with the maximum series fuse as specified. The modules' electrical performance in a string should be the same. When connected in series, all modules must have the same amperage. When connected in parallel, the modules must all have the same voltage. Connect the quantity of modules that match the voltage specifications of the inverters used in the system. The modules must not be connected together to create a voltage that is higher than the permitted system voltage.

Product can be irreparably damaged if an array string is connected in reverse polarity to another. Always verify the voltage and polarity of each individual string before making a parallel connection. If you measure a reversed polarity or a difference of more than 10V between strings then check the string configuration before making the connection.

Before wiring the module, ensure that the contact points are corrosion free, clean and dry; If a string of modules is reversed, irreparable damage can be caused.

Each LEDVANCE PV module has two PV cables which can withstand 85°C temperature and they are sunlight resistant (UV). The cross-sectional area of the cable is 4mm² or 12AWG, and the external diameter is 5mm~7mm. The minimum bending radius of the cables must be 43mm. Any cable damage caused by bending too much or improper cable management is not covered under LEDVANCE's warranty. Connectors are included at the end of each cable. All other cables used to connect the direct current system shall have similar (or higher) specifications, and should have the suitable insulation ability which can suffer the possible maximum system Voc (as defined in TÜV 2PFG1169, EN50618 (H1Z2Z2-K or IEC62930). LEDVANCE requires all cables and electrical connections to comply with the electrical regulations of the countries where the PV system is installed.

All electrical performance parameters were obtained under standard test conditions (1000W/m², 25±2°C, AM 1.5, according to IEC 60904-3).

Temperature coefficient for voltage at open-circuit; (refer to data sheet) **Voc**

Temperature coefficient for short-circuit current; (refer to data sheet) **Isc**

Temperature coefficient for maximum power. (refer to data sheet) **Pmpp**

Under normal conditions, a PV module is likely to experience conditions that produce higher current and/or voltage than reported at standard test conditions. Accordingly, the values of Isc and Voc. marked on this PV module should be multiplied by a factor of 1.25 at least when determining component voltage ratings, conductor and protection devices current ratings, etc. (e.g. inverter) connected to the PV output.

INSTALLATION

When selecting a cable, the minimum current-carrying capacity of the cable can be calculated by the following formula.

Minimum current-carrying capacity of the cable = $1.25 \cdot I_{sc} \cdot N_p$


I_{sc} : short-circuit current of PV module (unit: A)

N_p : the number of modules in parallel or module strings


To ensure proper system operation the correct cable connection polarity (Figures 1 & 2) should be observed when connecting the modules to each other or to a load, such as inverter, a battery etc. If modules were not connected correctly, the bypass diodes could be destroyed. PV modules can be wired in series to increase voltage. A series connection is made when the wire from the positive terminal of one module is connected to the negative terminal of the next module. A parallel connection is made when the wire from the positive terminal of one module is connected to the positive terminal on the next module. Do not connect strings with Y or T connector without any anti-reverse current protection devices. Installers should independently calculate and verify the appropriate application and how to connect strings in parallel.

When conducting electrical connection of the modules, use diagonal pliers to cut the cable tie. When cutting the tie, be careful not to scratch the cables or the backside of the module. The positive and negative connectors should be connected in turn, and confirm that you hear a "click" to indicate that the connection is successful. Otherwise, during the operation of the modules, this could lead to electric arc due to poor connections and can burn the connectors. It is not recommended to interconnect different types of connectors.

Series and Parallel Connection




Series Connection



Parallel Connection

INSTALLATION

Parallel – Series Connection



Before the commissioning and operation of the power station, check the electrical connection of modules and strings, making sure all connection polarity is correct and the open circuit voltage meets the requirements of the acceptance criteria.

The number of modules in series and in parallel shall be designed reasonably according to the system configuration.

LEDVANCE recommends using lightning protection devices which are complied with local laws and electrical regulations.

All the above instructions must be followed to meet LEDVANCE warranty conditions.

2. Bypass diode

The junction boxes used with LEDVANCE modules contain bypass diodes wired in parallel with the PV cell strings. In the case of partial shading, the diodes bypass the current generated by the non-shaded cells, thereby limiting modules heating and performance losses. Bypass diodes are not over-current protection devices.

Each module has three diodes. Replacement of the bypass diode is allowed only by an authorized service technician.


INSTALLATION

3. Grounding

All module frames and mounting racks must be properly grounded in accordance with the electrical design and construction specifications, procedures, regulations and other special grounding requirements applicable to the installation sites.

Proper grounding can be achieved by connecting the module frame(s) and all metallic structural components together by using a suitable grounding conductor. The grounding conductors or wires may be copper, alloy, or any other materials that are in accordance with the local electrical design and construction specifications, procedures, and regulations. It is recommended to use the copper wire (4-16mm² or AWG 6-12) as the grounding wire. The sign "⚡" can be found at the grounding hole position. The ground wire must also be connected to ground through a suitable ground electrode. The tight connection of all the joint point should be ensured.

On a grounding hole with a diameter of 4 mm, use a separate grounding wire and related accessories to connect the aluminum frame of the solar PV module and connect the grounding wire to the ground. The grounding uses the M4*12mm bolts and M4 nuts, star washers and plain washers, this ensures that the modules are firmly grounded. You can find the corresponding product drawing in module datasheet to know the detailed number, size and position of the grounding holes. The torque applied to ground fixation is 4Nm~8Nm. Do not drill any extra ground holes for convenience, this will void the modules warranty. LEDVANCE recommends using grounding wires with resistances that are less than 1Ω.



INSTALLATION

When grounding, each module can be grounded directly or in series or in parallel. If you choose the latter two options, it is recommended that the maximum number of modules connected in parallel should not exceed four, and in series should not exceed eight.

In addition to use the grounding hole, you can also choose the following grounding ways:

- Grounding by unused mounting holes
- Other professional grounding devices

The electrical contact points of all the above grounding methods should penetrate the anodized film of the aluminum frame. PV modules can be grounded by other grounding devices, which must be reliable and certified. The manufacturer's requirements should be followed.

MODULE MAINTENANCE

In order to ensure the long-term using of the installed PV system and maximize the power output performance of the modules, the installed PV modules need to be inspected and maintained every 6 months, which is the responsibility of the users. The inspection and maintenance of modules in the PV array shall be carried out by personnel who have received professional PV system maintenance training and obtained relevant qualifications and authorization.

PANEL VISUAL INSPECTION AND REPLACEMENT

The modules in a PV array should be regularly checked for damage. Factors such as glass breakage, cable breakage, junction box damage and improper or loose terminations may lead to function and safety problems. In the case of a damaged module, replace it with the same type of module. Do not touch live parts of cables and connectors. Use appropriate safety equipment (insulated tools, insulating gloves, etc.) when handling modules. Refer to the appropriate Product Installation Manual for installation and disassembly of module.

Check the electrical, grounding and mechanical connections every 6 months to ensure they are clean and safe, free from damage or rust. Check that all string fuses in each non/earthed pole are operating. Check that the mounting parts are tight. Check all cables and make sure that the connectors are secured. PV modules frames and bracket should be well mechanically connected.

Check whether there is any foreign body on the surface of the PV modules and whether there is any shielding. The vegetation should be cut regularly to avoid shading and thus affecting the module's performance.

When repairing PV modules, cover the surface of PV modules with opaque material to prevent electric shock. Exposure of PV modules to sunlight will generate high voltages, this is dangerous. Pay attention to safety when maintenance and it must be done by authorized professionals.

Wear cut resistant gloves and other personal protective equipment required for the particular installation. Isolate the impacted array string to prevent current flow before attempting to remove the module. Disconnect the connectors of the affected module. Replace the damaged module with a new functional module of the same type.

In a system using a battery, blocking diodes are typically placed between the battery and the PV module output to prevent battery discharge at night.

When the irradiance is no less than 200W/m^2 , if the terminal voltage is more than 5% different than the rated value, it illustrates the connection of the modules is not good.

Comply with maintenance instructions for all components used in the PV system, such as brackets, charging rectifiers, inverters, batteries, lightning protection systems, etc.

Warning: The warning signs on the PV modules must not be lost. Any electrical maintenance must shut down the PV system firstly. Improper system maintenance may cause fatal dangers such as electric shock and burning. Observe the safety precautions listed earlier in this Manual.

MODULE MAINTENANCE

CONNECTOR AND CABLE INSPECTION

It's recommended to implement the following preventive maintenance every 6 months:

- Check the sealing gels of the junction box for any damage.
- Examine the PV module(s) for signs of deterioration. Check all wiring for possible rodent damage, weathering and that all connections are tight and corrosion free. Check electrical leakage to ground.
- Inspect all cables to verify that connections are tight, the cables are protected from direct sunlight and sited away from areas of water collection.
- Check the torque of terminal bolts and the general condition of wiring. Also, check that mounting hardware is properly torqued. Loose connections will result in damage to the array.

CLEANING

Dust accumulation on the glass surface of the module will reduce its power output and may cause hot spots. So the surface of PV modules should be kept clean. Maintenance work should be performed at least once 6 months or frequently.

Warning: It should be carried out by trained personnel. Workers should wear PPE, such as goggles, electric insulation gloves and safety shoes. The gloves should withstand DC voltages of no less than 2000V. Cleaning activities create risk of damaging the modules and array components, as well as increasing the potential electric shock hazard. Cracked or broken modules represent an electric shock hazard due to leakage currents, and the risk of shock is increased when modules are wet. Before cleaning, thoroughly inspect modules for cracks, damage, and loose connections.

Make sure that the array has been disconnected from other active components before starting the cleaning. Do not immerse the module, partially or totally, in water or any other cleaning solutions.

Use dry or wet soft cloths, sponges, etc. to clean the modules during the cleaning process, but do not put any modules directly into the water, do not use corrosive solvents and do not wipe the PV modules with hard objects. When the pressure water is used, the water pressure on the glass surface of the module must not exceed 700 KPa. The module must not be subjected to additional external force. If there is greasy dirt and other substances on the surface of the PV module which are difficult to clean, conventional household glass cleaning agents can be used; Do not use the alkaline and strong acid solvents. If necessary, use isopropyl alcohol (IPA) or other solution according to the safety instructions to clean and ensure that no solution flows into the gap between the edge of the module and the module frame.

Clean PV modules when the irradiance is below 200W/m². When cleaning the modules, use a soft cloth together with a mild detergent and clean water. Take care to avoid severe thermal shocks which might damage the module by cleaning modules with water which make sure the temperature difference between the water and the module is in the range of -5°C~10°C. For example, do not use cold water to clean the module when the temperature of it is high during the day, otherwise there will be the risk of module damage.

It is forbidden to clean PV modules under the weather conditions of wind more than grade 4 (in Beaufort scale), heavy rain or heavy snow.

When cleaning PV modules: do not step on the modules, do not spray water on the backside of the module or the cables, keep the connectors clean and dry, prevent fire and electrical shock from occurring, do not use as steam cleaner.

MODULE MAINTENANCE

The back surface of the module normally does not need to be cleaned but, in the event this is deemed necessary, avoid the use of any sharp projects that might damage the penetrating the substrate material.

When cleaning the back surface of the module, take care to avoid penetrating the substrate material. Modules that are mounted flat (0° tilt angle) should be cleaned more often, as they will NOT "self-clean" as effectively as modules mounted at a 10° tilt or greater.

Do not scrape or grind stains off surfaces while PV modules are dry, as this can cause minor scratches on the surface.

Cleaning methods:

Method 1: Compressed water

Requirement for water quality:

- pH: 5~7
- Chloride or salt content: 0~3000 mg/L
- Turbidity: 0~30 NTU
- Conductivity: 1500~3000 $\mu\text{S}/\text{cm}$
- Total dissolved solids (TDS): ≤ 1000 mg/L
- Water hardness (calcium and magnesium ions): 0~40 mg/L
- Non-alkaline water must be used, and softened water can be used when conditions permitted

Method 2: Compressed Air

LEDVANCE recommends using this method to clean the soft dirt (like dust) on modules.

This technique can be applied as long as the method is efficient enough to clean the modules considering the on-site conditions.

Method 3: Wet cleaning

If excessive soiling is present on the module surface, a non-conductive brush, sponge, or other mild agitating method may be used with caution.

Make sure that any brushes or agitating tools are constructed with non-conductive materials to minimize risk of electric shock and that they are not abrasive to the glass or the aluminum frame.

If grease is present, an environmentally friendly cleaning agent may be used with caution.

Method 4: Cleaning robot

If a cleaning robot is used for dry cleaning, the brush material is required to be soft plastic material, and the glass surface and aluminum alloy frame of the module will not be scratched during the cleaning process and after cleaning. The weight of the cleaning robot should not to be too large. If the cleaning robot is improperly used, and the resulting module damage and power attenuation are not covered by LEDVANCE's warranty.

MODULE INSPECTION AFTER CLEANING

- Ensure that the module under visual inspection is clean, bright and free of stains
- Spot check to verify whether there is soot deposit on the module surface
- Check to whether there are visible scratches on the surface of the module or not
- Check whether there is no man-made cracks on the module surface or not
- Check whether the module support structure is leaning or bent or not
- Check whether the connectors of the module are detached or not
- After cleaning, fill out the PV module cleaning record

MODULE MAINTENANCE

TROUBLE SHOOTING

If the PV system does not work properly, inform your installer immediately. It is recommended to perform a preventive inspection every 6 months.

If electrical or mechanical properties are required for inspection or maintenance, qualified professionals should be advised to avoid any electric shock or loss of life.